VILTROX

EF-M2 MOUNT ADAPTER

VILTROX MOUNT ADAPTER EF-M2 0.71x

Thank you for using Viltrox mount adapter !

* Before setting the Viltrox mount adapter on your camera, please read this instruction so that all functions of the mount adapter will be implemented.

🔲 Product function

Viltrox EF-M2 mount adapter is designed to allow Canon EF-mount series lenses to be used on M43 cameras. Plus 0.71 based on the original focal length (equivalent focal length=focal length x0.71), which helps increase 1 stop aperture. Build-in 4 groups, 4 pcs optical glasses, By adapter mounting it can achieve functions of EXIF signal transmission, AF (autofocus) and aperture adjustment,etc. Firmware upgrade can be operated via the USB port.

Make sure the camera is compatible with the lens before using the adapter.Please read the manual carefully so that you can know more about proper operations before using the product.In order to help you refer later at any time ,pls take good care of the manual.

Attentions

1. After mounting the adapter on the lens and setting the MF mode to AF mode, if autofocus still doesn't work, please restart the camera.
2. Please use the switch on the lens to set the lens function.
3. If the settings in camera menu differ from those on the lens, settings on the lens shall prevail.
4. When the lens you use is much heavier than the camera, be sure to hold the lens when moving the camera or shooting.
   Since the minimum focusing distance will increase with the adapter mounted, the maximum magnification and filed of view may change.

Name of each part

Lens mount index

Optical glasses

Lens release lever

Contacts (lens side)

Aperture adjustment

Camera lens mount index

USB Upgrade

Contacts (camera side)

Tripod socket

1/4" Standard interface

📇 Mounting and Detaching the Adapter

◎ Mounting procedures

1. Attach the EF lens to the EF mount side of the adapter.
Insert the lens into the adapter by aligning the mount index found on the EF lens (red circle) with the same mark found on the adapter, and turn the EF lens clockwise until you hear a click. (fig. ❶)

2. Mount the adapter to the camera.
Insert the adapter into the camera by aligning the Canon EF lens mount index found on the adapter (Red circle) with the same mark found on the camera, and turn the adapter counter clockwise until you hear a click. (fig. ❷)

◎ Detaching procedures

1. Turn the camera OFF, and detach the adapter from the camera while the EF lens is still attached to it.
Turn the adapter counter clockwise while pressing the camera's lens release button. Detach the adapter once it has stopped turning.

2. Detach the EF lens from the adapter.
Turn the EF lens counter clockwise while pushing the lens release lever on the adapter .Detach the EF lens once it has stopped turning.

📋 Attaching the tripod mount

1. Attach the included tripod mount to the adapter by firmly turning the tripod mount knob.
   Please make sure that the tripod mount is facing in the correct direction in relation to the adapter.

2. Attach the tripod using the tripod mount socket.Securely attach the tripod while firmly holding the adapter.

3. Precautions when using this adapter with a tripod.
   When shooting with a tripod, do not use the camera's tripod mount socket while the adapter is attached. Be sure to use the tripod mount included with the adapter.

⚠ When using a tripod with EF lenses that are equipped with a tripod mount, such as super telephoto lenses, please be sure to use it to mount the lens to the tripod.

Attention: Before upgrading, please detach the mount adapter from camera in case that will influence the camera performance.

Method of firmware upgrading:
1. Connect the mount adapter to computer with a USB cable;
2. With upgraded files downloaded to the drive of the device, U disk will automatically reset and the original files will be deleted. Upgrade is completed

🔲 Specifications

Compatible lenses	Canon EF series lenses
Compatible cameras	M43 series cameras
Focus mode	Auto focus
Focal Lenth Multiplier	0.71x
Optical glasses	4 groups, 4 glasses
Firmware upgrade	USB upgrade port
Tripod Socket	Cu1/4"× 1
Diameter and Length	67mm×20mm
Weight	Approx. 118 g (excluding cap)
Front cap	Camera cover
Rear cap	Lens Dust cap